

## C. UPGRADED PART NUMBERS

Original Part No.	Upgraded By	Original Part No.	Upgraded By	Original Part No.	Upgraded By	Original Part No.	Upgraded By	Original Part No.	Upgraded By	Original Part No.	Upgraded By
3834185S	3958485S	HF6177	HF7980	LF3333	LF3380						
3925469S	3959125S	HF6202	HF6344	LF3342	LF3789						
3935185S	3958484S	HF6243	HF6318	LF3345	LF3553						
AF1748	AF1748M	HF6271	HF6373	LF3346	LF3656						
AF1817	AF1817M	HF6309	HF7961	LF3349	LF3552						
AF1968	AF1968M	HF6319	HF28978	LF3363	LF9325						
AF1968	AF26328	HF6354	HF28979	LF3374	LF9691						
AF1968M	AF26328M	HF6356	HF28975	LF3379	LF9667						
AF1969	AF1969M	HF6373	HF6270	LF3380	LF9333						
AF25757	AF25636	HF6578	HF6518	LF3413	LF3687						
AF864	AF864M	HF7000	HF30430	LF3420	LF3560						
AF872	AF872M	HF7000	HF35181	LF3453	LF9747						
AF879	AF879M	HF7005	HF30108	LF3493	LF3765						
AF910	AF910M	HF7008	HF30634	LF3548	LF9548						
AF979	AF979M	HF7010	HF30340	LF3559	LF3919						
AF982	AF982M	HF7012	HF30691	LF3566	LF9691A						
AH1135	AH1135M	HF7017	HF30181	LF3620	LF3671						
AH1135F	AH1135M	HF7018	HF30364	LF3620	LF9620						
CC2650	CC2651	HF7021	HF30123	LF3671	LF9620						
FF104	FF5334	HF7024	HF30645	LF3681	LF16002						
FF104	FF105	HF7028	HF30451	LF3737	LF3773						
FF105	FS1212	HF7032	HF30515	LF3746	LF3918						
FF105	FF5332	HF7033	HF30154	LF3781	LF3931						
FF171	FF5347	HF7036	HF30602	LF3781	LF9931						
FF172	FS1219	HF7040	HF30383	LF3931	LF9931						
FF185	FS1214	HF7041	HF30028	LF3945	LF16104						
FF185	FF5336	HF7042	HF30199	LF3959	LF3894						
FF196	FS1220	HF7044	HF30436	LF3972	LF16035						
FF202	FS1216	HF7045	HF30062	LF4054	LF3687						
FF202	FF5346	HF7046	HF30236	LF551A	LF3487						
FF211	FS1218	HF7052	HF30517	LF581	LF3538						
FF222	FF5348	HF7053	HF30156	LF651	LF3488						
FF5018	FS1221	HF7054	HF30288	LF653	LF3488						
FF5020	FS1225	HF7057	HF30131	LF654	LF3788						
FF5021	FF5335	HF7058	HF30331	LF667	LF9667						
FF5052	FS1251	HF7062	HF30346	LF667	LF3379						
FF5206	FF5333	HF7064	HF30402	LF670	LF3363						
FF5207	FS19513	HF7065	HF30036	LF670	LF9325						
FF5337	FF5323	HF7066	HF30210	LF691	LF3374						
FF5369W	FS1029W	HF7067	HF30697	LF691	LF9691						
FF5369W	FS19536	HF7068	HF30453	LF691A	LF3566						
FF5392	FS19550	HF7069	HF30084	LF691A	LF9691A						
FS1003	FS19596	HF7070	HF30262	LF747	LF3453						
FS1011	FS1020	HF7072	HF30524	LF747	LF9747						
FS1029W	FS19727	HF7076	HF30584	LF782	LF3554						
FS1040	FS1007	HF7088	HF30455								
FS1201	FS19553	HF7089	HF30085								
FS1206	FS1293	HF7092	HF30582								
FS1207	FS1294	HF7093	HF30118								
FS1212	FS1242B	HF7101	HF30022								
FS1212	FS1000	HF7104	HF30442								
FS1216	FS1006	HF7105	HF30071								
FS1242	FS1015	HF7106	HF30244								
FS1242	FS1015B	HF7121	HF30457								
FS1242B	FS1015B	HF7125	HF30510								
FS1253	FS19519	HF7130	HF30112								
FS1253V	FS19519V	HF7131	HF30310								
FS19559	FS19557	HF7313	HF7317								
FS19629	FS19867	HF7468	HF30454								
FS19762	FS19557	HF7472	HF30525								
FS19762	FS19559	HF7492	HF30583								
HF28766	HF28753	HF7518	HF30570								
HF6056	HF7608	HF7520	HF30114								
HF6083	HF6339	HF7527	HF30281								
HF6089	HF6340	HF7530	HF30113								
HF6090	HF28980	HF7604	HF6005								
HF6097	HF6341	LF3000	LF9009								
HF6098	HF6342	LF3313	LF3487								
HF6101	HF28977	LF3316	LF3559								
HF6109	HF7332	LF3316	LF3919								
HF6110	HF6343	LF3321	LF9667								
HF6118	HF6271	LF3321	LF3379								
HF6140	HF6348	LF3325	LF9325								
HF6164	HF6446	LF3325	LF3363								
HF6173	HF7983	LF3333	LF9333								

\* This table indicates filter part numbers that have been removed from our product line. Please note that some obsolete products have been replaced by new part numbers that are indicated in the "Replaced By" column. If no part appears in that column, the product is no longer available and has no replacement.